
ARICA - AP CHACALLUTA

SCAR - STAR 2 RNAV RWY 03

VAGUR 5B / SIRAM 3B



Nivel de Transición por ATC
Transition Level by ATC

No se ajusta a escala / *Not to scale*

STAR VAGUR 5B / SIRAM 3B RNAV

VAGUR 5B: Desde VAGUR proceder via ISASO - ATIPA - ERISO, viraje dercha para continuar via AR390 - AR270 - AR220 - BOLUN. Cruzar VAGUR FL210 o superior, ISASO FL200 o superior, ATIPA FL 170 o superior, ERISO FL150 o superior, AR390 FL120 o superior, AR270 7000 FT o superior, AR220 6000 FT o superior, BOLUN 5000 FT o superior, luego según autorización ATC.

VAGUR 5B: *From VAGUR proceed via ISASO - ATIPA - ERISO, right turn to continue via AR390 - AR270 - AR220 - BOLUN. Cross VAGUR at or above FL210, ISASO at or above FL200, ATIPA at or above FL170, ERISO at or above FL150, AR390 at or above FL120, AR270 at or above 7000 FT, AR220 at or above 6000 FT, BOLUN at or above 5000 FT, then according to ATC clearance.*

SIRAM 3B: Desde SIRAM proceder via DONPU - SIGOR. Cruzar SIRAM y DONPU 8000 FT o superior, SIGOR 3500 FT o superior, luego según autorización ATC.

SIRAM 3B : *From SIRAM proceed via DONPU - SIGOR. Cross SIRAM and DONPU at or above 8000 FT, SIGOR at or above 3500 FT then according to ATC clearance.*

DASA / SECCION AIS-MAP